









©2016 Sony Corporation Printed in Malaysia




2















 "Power On"

3



 "Play"



Windows



Mac



http://rd1.sony.net/help/dmp/nwws410/h_ww/

